

Original Recipe by:  
Chris van  
Hammersveld

## PORTRAIT OF VAN GOGH WITBIER

### BREW DAY

Stage/Time	Type	Qty	Name	%AA	IBU
Steep	Grain	10.5 lb	Flaked Oats	-	-
Boil/60 min	Hop	1.65 oz	Saaz	3.1%	16.8
Boil/15 min	Extract	3 lb	Pilsen Light DME	-	-
		3 lb	Wheat DME	-	-
	Clarifier	1 tab	Whirlfloc	-	-
	Nutrient	1 tsp	Yeast Nutrient	-	-
Boil/5 min	Hop	0.5 oz	Saaz	3.1%	0.6
	Spice	0.6 oz	Coriander Seed (Crushed)	-	-
		0.9 oz	Bitter Orange Peel	-	-



#### Witbier (24A)

Original Gravity: 1.044 – 1.052 SG

Final Gravity: 1.008 – 1.012 SG

Bitterness: 8 – 20 IBUs

ABV: 4.5 – 5.5%

SRM: 2 - 4

Overall Impression: A refreshing, elegant, tasty, moderate-strength wheat-based ale. Moderate malty sweetness with light, grainy, spicy wheat aromatics, often with a bit of tartness. Moderate perfumy coriander, often with a complex herbal, spicy, or peppery note in the background. Moderate zesty, citrusy-orangey fruitiness.

### FERMENTATION AND BEYOND

Stage	Type	Qty	Name	Notes
Pitch	Yeast	1 pkg	WLP400 Belgian Wit	68 – 72°F

### TARGET STATS

Batch Size	5 gal
Original Gravity	1.051
Final Gravity	1.011
~%ABV	5.1
IBU	18
SRM	3.3

### BREW NOTES

Boil Duration	60 min

### Notes

Pitch your yeast and ferment at 68°F for 3 days before increasing the temperature by 2°F every day until it reaches 72°F, then hold until finished. Carbonate to 3 volumes of CO<sub>2</sub>.

# QUICK BREWING INSTRUCTIONS

PREP	Measure out all your ingredients ahead of time: <ul style="list-style-type: none"><li>- 3 gallons of water in your boil kettle</li><li>- 3 gallons of sanitized, pre-chilled water in the fridge</li><li>- All boil additions, ideally marked with their appropriate timings</li></ul>	
STEEP	Not all recipes will call for steeping grains, since some beers benefit from being as dry in flavor and pale in color as possible. Steeping grains are used to increase the color, the sweetness, and the overall density of your finished beer. Think of it like making a very large cup of malt tea, except you don't want to use boiling water. Your ideal temperature range for the steep is between 150 and 155°F. <ol style="list-style-type: none"><li>1. Heat your water up to 158°F, then turn off your heat and add your steeping bag of grain. This should bring the temperature down to 155°F or so. The larger your bag of steeping grains, the more it will change the temperature of the water.</li><li>2. Cover the pot with a lid to maintain temperature for 30 minutes.</li></ol> After 30 minutes, remove the grain from the pot and let it drip over the pot for a few moments before discarding. Do not squeeze or wring out the bag.	
BOIL	The purpose of your boil is to: [1] to sanitize, [2] to extract bitterness (alpha acids) from hops, and [3] to break down particulates for a clearer finished product. The total boil time is largely determined by how bitter you intend the beer to be. The extract only needs to be boiled long enough to sanitize and break down particulates, which is why our recipes usually add extracts in the last 15 minutes of the boil. <ol style="list-style-type: none"><li>1. Once your steep is complete and the grain bag is removed, begin heating your pot to a boil.</li><li>2. Once you achieve a stable rolling boil, start your timer for the total boil time (see recipe) and begin adding your additions at the appropriate times. With each addition, be sure to add slowly and keep an eye out for boil-overs.</li><li>3. In between additions, you should take the opportunity to make a bucket for sanitizing any equipment that will contact your unfermented beer (called "wort") after the boil.<ol style="list-style-type: none"><li>a. Measure out 5 gallons of water in your fermentor and add 1 oz of sanitizer. If you haven't already, be sure to mark your fermentor at the 5 gallon level for later.</li><li>b. After about a minute, transfer the solution into a bucket to sanitize the rest of your equipment (e.g. funnel, airlock, stopper, wine thief, etc.)</li></ol><b>Note:</b> If it's a glass fermentor, <b>do not pick it up</b> and attempt to pour it out; use a siphon to transfer the liquid safely.</li><li>4. With 15 min left of the boil, turn off the heat to the pot. Slowly add your malt extract, constantly stirring to ensure that it is completely dissolved. When clumps are no longer visible, turn the heat back on to resume boiling. At this point, boil-overs are much more likely, so have countermeasures ready. When the foam begins to rise rapidly:<ol style="list-style-type: none"><li>a. Be prepared to turn the heat down or off.</li><li>b. Have a spray bottle of water ready to help keep the foam at bay.</li><li>c. If the foam does not re-incorporate into the wort on its own, the heat is too high.</li></ol></li><li>5. Add any further additions at the appropriate times and begin preparing your cooldown bath.</li></ol>	<div>60 MIN</div> <ul style="list-style-type: none"><li>• 1.65 oz Saaz</li></ul>
		<div>15 MIN</div> <ul style="list-style-type: none"><li>• 3 lb Pilsen DME</li><li>• 3 lb Wheat DME</li><li>• Clarifier &amp; Nutrient</li></ul>
		<div>5 MIN</div> <ul style="list-style-type: none"><li>• 0.5 oz Saaz</li><li>• 0.6 oz Coriander</li><li>• 0.9 oz Bitter Orange Peel</li></ul>
COOLDOWN	Now that your boil has concluded, everything that touches your wort must be sanitized. Cooling your wort down to pitchable temperatures is important to improve clarity and to reduce the chances of bacterial infection. <ol style="list-style-type: none"><li>1. Transfer the hot kettle from the burner to a sink or tub filled with cold water. Carefully swirl the pot to better cool the wort inside.<b>Note:</b> Do not add ice at this time. Cold tap water should be enough of a contrast to rapidly cool your near-boiling wort to more manageable temperatures. Save the ice for the hard part (i.e. getting from 120°F to 80°F or lower).</li><li>2. As the water becomes hot, refill your tub with cool water until the wort gets below 150°F. At this point adding ice to the bath can help cool the wort to target more quickly.</li><li>3. Once your wort has cooled to 80°F or less, vigorously pour it into your sanitized fermentor. Add the prepared, sanitized cold water (refrigerating the water as suggested in the prep stage will help to cool your wort even further) to the fermentor until the total volume has reached 5 gallons.</li></ol> Shake the carboy for a few minutes to oxygenate and to evenly mix the water with your wort. Now is the time to take a hydrometer reading and record your Original Gravity measurement.	
PITCH	Adding your yeast is what changes the liquid in your fermentor from "wort" to "beer." <ol style="list-style-type: none"><li>1. Sanitize the exterior of the yeast package as well as any tools used to open it.</li><li>2. Add your yeast to the fermentor and seal with an airlock and stopper—being sure to fill the airlock to the appropriate mark with sanitizing solution.</li><li>3. Store in a cool dark place for the duration of fermentation.</li></ol>	WLP400 Belgian Wit Yeast <i>Ferment at 68 - 72°F</i>